Now .....
When i put my video card in and turn on my pc:
First it shows the big E(emachines)
Second it should the Windows Xp sign and there is a loading thing on the bottom
Third thing , the screnn goes blank and then i war few secons and the screens turns into multiple collers , it is like really color full but it is not what i want to see.
What happened?