Subject: how do u raise ur cpu bus speed!!!! Posted by Bearxor on Fri, 05 Sep 2003 17:23:38 GMT

View Forum Message <> Reply to Message

Pentium 4 Processors use a quad-pumped FSB. AthlonXP Processors use a double-pumped FSB.

What's this mean?

P4 Processor @ 200mhz FSB = 800mhz FSB AXP @ 166mhz FSB = 333 FSB

In other words, 200mhz FSB is right for your processor. If you were to raise it to 250, you would have a 1ghz FSB