

---

Subject: Welding

Posted by [Anonymous](#) on Thu, 16 Jan 2003 08:23:00 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Only happens with MIG, and Stick welding. TIG has no sparks unless you're doing it wrong. Just an arc, and filler wire.

---