
Subject: Sound DisOrder

Posted by [blackhand456](#) on Sat, 18 Sep 2004 22:57:49 GMT

[View Forum Message](#) <> [Reply to Message](#)

For the past 2 months i've had a sound echo coming out of my speackers, i've put up with it but now my micropone has failed....I need my microphone to record something...i've tried to reinstall my sound driver, didn't work. I've tried to reset my settings to default, nothing happened...

any ideas?
