

---

Subject: Re: NOOOOO

Posted by [Javaxcx](#) on Sat, 08 Oct 2005 23:33:33 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Most, if not all CD/DVD-ROM devices have a pin sized hole to open them in a case like this. You need a fairly small pin. Just force the mechanism and it should become loose enough for you to pull out.

---