

---

Subject: Re: Computer trouble

Posted by [Scythar](#) on Fri, 06 Jan 2006 12:09:39 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

1. Make sure the power switch wire is attached to motherboard.
  2. Have you unplugged the powercord at any time? Try it if not.
  3. Since it crashed before this, it really does sound like it overheated or something just plain broke. Take it to techies if you can't test it yourself with spare parts.
-