

---

Subject: Re: So...

Posted by [Caveman](#) on Fri, 28 Sep 2007 23:39:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

If when you turn on your computer it just beeps untill you turn it off it could be many things but its likely the RAM is not in correctly and/or has blown. Another cause could be the CPU. Double check that all the pins are securely in the socket.

---