

---

Subject: Re: So...

Posted by [Caveman](#) on Sat, 29 Sep 2007 01:25:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I can't see how the DVI connector is being used when you have onboard VGA. Most mobos don't have DVI. Define DVD wont work..What wont open, wont read etc.. Try resetting the CMOS. There should be a jumper on the mobo near the battery to do so. If you cannot find the jumper take out the battery for 5secs and then put it back in.

If you seriously smelt something burning then you might have to send the mobo back. Anymore help from me will have to wait 'till the morning. I need to sleep.

---