Subject: Renegade confige
Posted by DaddyD302 on Sun, 13 Jul 2003 22:15:52 GMT

Just bought a 9700pro a few weeks ago, and I just notice that under performance, the details keep resetting itself. I treid to run it at it's higest settings but it keeps resetting. It does this when I try to enable Anisotropic. I use the omega 3.4 driver with rage3d and it's at max settings on qualitity. I run everything at max and force AA and AF at their max settings. Yes I did the confige before I tried playing the game. I also tried doing this during the game and it still resets itself, truform doesn't work either. Anyone knows what I did wrong?