
Subject: Re: i got a problem

Posted by [Distrbd21](#) on Sat, 18 Oct 2008 05:32:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

It's a sata drive in an external case.

i use win xp geting sp3 now it has 2 hours left.

here are some pics of the settings.

where is device manage?

And yes it show's up in diskmanagement.

Anything else?

edit: on the kit it has place's for memory card's from camera's could that be causing it?

File Attachments

1) [untitled.JPG](#), downloaded 782 times

Generic USB CF Reader USB Device Properties

General Policies Volumes Driver

 Generic USB CF Reader USB Device

Device type: Disk drives
 Manufacturer: (Standard disk drives)
 Location: Location 0

Device status

This device is working properly.
 If you are having problems with this device, click Troubleshoot to start the troubleshooter.

Troubleshoot...

Device usage:
 Use this device (enable)

OK Cancel

Generic USB CF Reader USB Device Properties

General Policies Volumes Driver

Write caching and Safe Removal

Optimize for quick removal
 This setting disables write caching on the disk and in Windows, so you can disconnect this device without using the Safe Removal icon.

Optimize for performance
 This setting enables write caching in Windows to improve disk performance. To disconnect this device from the computer, click the [Safely Remove Hardware](#) icon in the taskbar notification area.

Restore Defaults

OK Cancel

Generic USB CF Reader USB Device Properties

General Policies Volumes Driver

The volumes contained on this disk are listed below.

Disk: Disk 1
 Type: Removable (E:)
 Status: No Media
 Partition style: Not Applicable
 Capacity: 0 MB
 Unallocated space: 0 MB
 Reserved space: 0 MB

Volumes:

Volume	Capacity

Properties

OK Cancel

Generic USB CF Reader USB Device Properties

General Policies Volumes Driver

 Generic USB CF Reader USB Device

Driver Provider: Microsoft
 Driver Date: 7/1/2001
 Driver Version: 5.1.2535.0
 Digital Signer: Microsoft Windows Publisher

Driver Details... To view details about the driver files.

Update Driver... To update the driver for this device.

Roll Back Driver If the device fails after updating the driver, roll back to the previously installed driver.

Uninstall To uninstall the driver (Advanced).

OK Cancel