
Subject: Dreamcast Disc Repair Question
Posted by [nikki6ixx](#) on Tue, 18 Nov 2008 03:17:55 GMT
[View Forum Message](#) <> [Reply to Message](#)

One of my Dreamcast disc's is not being read by the system. The laser is fine, as it works for the other GD-ROM's, and CD's.

My question is whether anyone who had/has a Dreamcast knows the best way to repair the disc's; I know ways to repair CD's (toothpaste, etc.), but seeing as the GD-ROM is a slightly different animal which can be extra prone to scratches, is there a better, or more successful way?

I haven't had much luck poking around the web so far, and because the data is so tightly packed, even one scratch can render the game unplayable.
