

---

Subject: Re: Annoying problem

Posted by [zeratul](#) on Mon, 11 Jan 2010 23:40:47 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

danpaul88 wrote on Mon, 11 January 2010 01:49: Probably dirt on the sensors under the buttons on the mouse, if you have a compressed air can try pointing it beneath each of the buttons and giving it a quick blast.

That or buy a new mouse, they are hardly expensive... you can get a decent Logitech mouse for about £15.

problem with compressed air i have this model

<http://www.anumex.com/pictures/1061845-1.jpg>

cant get under the buttons

id try force but i dont feel like breaking it ... yet

would it just be better to get a new one?

---