

---

Subject: Hard drive help

Posted by [zunnie](#) on Sat, 03 Apr 2004 16:25:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

did you leave your old drive in it?

You must set one of the harddrive as 'Slave' and the other as 'Master'

and seriously dude: get someone who knows what he is doing or your pc may not work at all :/

[zunnie]

---