

---

Subject: Help YSLMuffins fix her soundcard!

Posted by [YSLMuffins](#) on Tue, 29 Jun 2004 04:58:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I understand the Renegade part, but I'm not sure why I have so many. Back when I had an ESS Solo card I just had one choice to use as an audio driver, now I have several with this Audigy card within Renegade. But in the control panel, I only have one. Where in Control Panel exactly do you mean? Under Sound and Audio Devices (I'm running Windows XP)? There, I only have one choice: SB Audigy Audio [C480]

---