

---

Subject: Renegade Alert Allied Turret

Posted by [PermaGrin](#) on Fri, 22 Oct 2004 05:42:18 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

PermaGrinHell, just remap sides and place the UVs over the UVs of the top and bottom pieces. Areas may not match perfectly, but atleast it wont be stretched.

---